# DATA 624 Project 2

## 1. Introduction

In this Notebook, we will attempt to build a model which will address the below mission statement. Using the applicable techniques at our disposal, we will attempt to predicatively estimate the PH of the manufacturing process at ABC Beverage. Additionally, we will provide a forecast for "new" data provided.

# 2. Mission Statement

Project #2 (Team) Assignment

This is role playing. I am your new boss. I am in charge of production at ABC Beverage and you are a team of data scientists reporting to me. My leadership has told me that new regulations are requiring us to understand our manufacturing process, the predictive factors and be able to report to them our predictive model of PH.

Please use the historical data set I am providing. Build and report the factors in BOTH a technical and non-technical report. I like to use Word and Excel. Please provide your non-technical report in a business friendly readable document and your predictions in an Excel readable format. The technical report should show clearly the models you tested and how you selected your final approach.

Please submit both Rpubs links and .rmd files or other readable formats for technical and non-technical reports. Also submit the excel file showing the prediction of your models for pH.

# 3. Method

In the below sections, we will begin by performing Exploratory Data Analysis with the goals of:

- 1. Identifying and determining treatments for any missing data
- 2. Understanding the variance of each predictor
- 3. Identifying relationships between predictors and the response variable

Once that is completed, we will then perform any data reprocessing necessary from the EDA performed.

At this point, our dataset will be ready for modeling and we will then build a series of Linear, Nonlinear, Regression, and Rule-Based models. We will be varying the inputs to find an optimal model.

The models we will build are: 1. Ordinary Linear Regression 2. Partial Least Squares (PLS) 3. Neural Network Model 4. Multivariate Adaptive Regression Splines (MARS) 5. Support Vector Machines (SVM) 6. K-Nearest Neighbors (KNN) 7. Random Forest 8. Boosted Trees 10. Cubist

# 4. EDA

Importing Libraries and reading in the data

```
start <- Sys.time()</pre>
# Install packages as necessary
pkgs <- c("fpp3", "caret", "RANN", "mlbench", "earth", "party", "Cubist", "gbm", "randomForest", "doPar</pre>
for (pkg in pkgs) {
 if (!requireNamespace(pkg, quietly = TRUE)) {
    install.packages(pkg)
}
## Registered S3 method overwritten by 'tsibble':
    method
                       from
##
    as_tibble.grouped_df dplyr
library(readxl)
library(tidyverse)
## -- Attaching core tidyverse packages ----- tidyverse 2.0.0 --
## v dplyr 1.1.4
                     v readr
                                 2.1.4
## v forcats 1.0.0 v stringr 1.5.1
## v ggplot2 3.5.1 v tibble 3.2.1
## v lubridate 1.9.3 v tidyr 1.3.0
## v purrr
            1.0.2
## -- Conflicts ----- tidyverse_conflicts() --
## x dplyr::filter() masks stats::filter()
## x dplyr::lag() masks stats::lag()
## i Use the conflicted package (<a href="http://conflicted.r-lib.org/">http://conflicted.r-lib.org/</a>) to force all conflicts to become error
library(pls)
##
## Attaching package: 'pls'
## The following object is masked from 'package:stats':
##
##
      loadings
library(fpp3)
## -- Attaching packages ------ fpp3 1.0.0 --
## v tsibble 1.1.5 v fable 0.3.4
## v tsibbledata 0.4.1
                       v fabletools 0.4.2
## v feasts 0.3.2
## -- Conflicts ----- fpp3_conflicts --
## x lubridate::date() masks base::date()
```

```
masks stats::filter()
## x dplyr::filter()
## x tsibble::intersect() masks base::intersect()
## x tsibble::interval() masks lubridate::interval()
## x dplyr::lag()
                        masks stats::lag()
## x tsibble::setdiff() masks base::setdiff()
## x tsibble::union() masks base::union()
library(caret)
## Loading required package: lattice
## Attaching package: 'caret'
## The following objects are masked from 'package:fabletools':
##
##
       MAE, RMSE
##
## The following object is masked from 'package:pls':
##
       R2
##
##
## The following object is masked from 'package:purrr':
##
##
       lift
library(RANN)
library(mlbench)
library(nnet)
library(earth)
## Loading required package: Formula
## Loading required package: plotmo
## Loading required package: plotrix
library(VIM)
## Loading required package: colorspace
## Loading required package: grid
## VIM is ready to use.
## Suggestions and bug-reports can be submitted at: https://github.com/statistikat/VIM/issues
## Attaching package: 'VIM'
## The following object is masked from 'package:datasets':
##
##
       sleep
library(party)
```

## Loading required package: mvtnorm

```
## Loading required package: modeltools
## Loading required package: stats4
##
## Attaching package: 'modeltools'
##
## The following object is masked from 'package:fabletools':
##
##
       refit
##
## Loading required package: strucchange
## Loading required package: zoo
## Attaching package: 'zoo'
##
## The following object is masked from 'package:tsibble':
##
##
       index
##
## The following objects are masked from 'package:base':
##
       as.Date, as.Date.numeric
##
## Loading required package: sandwich
##
## Attaching package: 'strucchange'
## The following object is masked from 'package:stringr':
##
##
       boundary
##
##
## Attaching package: 'party'
##
## The following object is masked from 'package:fabletools':
##
##
       response
##
## The following object is masked from 'package:dplyr':
##
##
       where
library(Cubist)
library(gbm)
## Loaded gbm 2.2.2
## This version of gbm is no longer under development. Consider transitioning to gbm3, https://github.c
library(randomForest)
## randomForest 4.7-1.2
## Type rfNews() to see new features/changes/bug fixes.
## Attaching package: 'randomForest'
```

```
##
## The following object is masked from 'package:dplyr':
##
##
       combine
##
## The following object is masked from 'package:ggplot2':
##
##
       margin
library(doParallel)
## Loading required package: foreach
## Attaching package: 'foreach'
##
## The following objects are masked from 'package:purrr':
##
##
       accumulate, when
##
## Loading required package: iterators
## Loading required package: parallel
library(elasticnet)
## Loading required package: lars
## Loaded lars 1.3
library(kernlab)
##
## Attaching package: 'kernlab'
## The following object is masked from 'package:modeltools':
##
##
       prior
## The following object is masked from 'package:purrr':
##
##
       cross
##
## The following object is masked from 'package:ggplot2':
##
       alpha
library(corrplot)
## corrplot 0.95 loaded
## Attaching package: 'corrplot'
## The following object is masked from 'package:pls':
##
##
       corrplot
```

```
# Specify URLS
train_data_url <- "https://github.com/riverar9/cuny-msds/raw/refs/heads/main/data624-predictive-analytic
new_data_url <- "https://github.com/riverar9/cuny-msds/raw/refs/heads/main/data624-predictive-analytics

# Download the files
download.file(train_data_url, destfile = "temp_train.xlsx", mode = "wb")
download.file(new_data_url, destfile = "temp_new.xlsx", mode = "wb")

# Read the files
student_train <- read_excel("temp_train.xlsx")
student_test <- read_excel("temp_new.xlsx")

# Delete the files
file.remove("temp_train.xlsx", "temp_new.xlsx")</pre>
```

## [1] TRUE TRUE

#### Inspecting the Data

# See train data info

```
str(student_train)
## tibble [2,571 x 33] (S3: tbl_df/tbl/data.frame)
## $ Brand Code
                     : chr [1:2571] "B" "A" "B" "A" ...
## $ Carb Volume
                     : num [1:2571] 5.34 5.43 5.29 5.44 5.49 ...
## $ Fill Ounces
                     : num [1:2571] 24 24 24.1 24 24.3 ...
## $ PC Volume
                    : num [1:2571] 0.263 0.239 0.263 0.293 0.111 ...
## $ Carb Pressure
                     : num [1:2571] 68.2 68.4 70.8 63 67.2 66.6 64.2 67.6 64.2 72 ...
                     : num [1:2571] 141 140 145 133 137 ...
## $ Carb Temp
## $ PSC
                    : num [1:2571] 0.104 0.124 0.09 NA 0.026 0.09 0.128 0.154 0.132 0.014 ...
## $ PSC Fill
                    : num [1:2571] 0.26 0.22 0.34 0.42 0.16 ...
## $ PSC CO2
                     : num [1:2571] 0.04 0.04 0.16 0.04 0.12 ...
## $ Mnf Flow
                    ## $ Carb Pressure1 : num [1:2571] 119 122 120 115 118 ...
## $ Fill Pressure : num [1:2571] 46 46 46 46.4 45.8 45.6 51.8 46.8 46 45.2 ...
                    : num [1:2571] 0 0 0 0 0 0 0 0 0 0 ...
## $ Hyd Pressure1
## $ Hyd Pressure2 : num [1:2571] NA NA NA 0 0 0 0 0 0 0 ...
## $ Hyd Pressure3 : num [1:2571] NA NA NA 0 0 0 0 0 0 0 ...
## $ Hyd Pressure4
                    : num [1:2571] 118 106 82 92 92 116 124 132 90 108 ...
## $ Filler Level
                     : num [1:2571] 121 119 120 118 119 ...
## $ Filler Speed
                    : num [1:2571] 4002 3986 4020 4012 4010 ...
## $ Temperature
                     : num [1:2571] 66 67.6 67 65.6 65.6 66.2 65.8 65.2 65.4 66.6 ...
                     : num [1:2571] 16.2 19.9 17.8 17.4 17.7 ...
## $ Usage cont
## $ Carb Flow
                     : num [1:2571] 2932 3144 2914 3062 3054 ...
## $ Density
                     : num [1:2571] 0.88 0.92 1.58 1.54 1.54 1.52 0.84 0.84 0.9 0.9 ...
## $ MFR
                     : num [1:2571] 725 727 735 731 723 ...
## $ Balling
                     : num [1:2571] 1.4 1.5 3.14 3.04 3.04 ...
## $ Pressure Vacuum : num [1:2571] -4 -4 -3.8 -4.4 -4.4 -4.4 -4.4 -4.4 -4.4 -4.4 ...
## $ PH
                     : num [1:2571] 8.36 8.26 8.94 8.24 8.26 8.32 8.4 8.38 8.38 8.5 ...
                     : num [1:2571] 0.022 0.026 0.024 0.03 0.03 0.024 0.066 0.046 0.064 0.022 ...
## $ Oxygen Filler
## $ Bowl Setpoint
```

```
## $ Pressure Setpoint: num [1:2571] 46.4 46.8 46.6 46 46 46 46 46 46 ...
   $ Air Pressurer
                        : num [1:2571] 143 143 142 146 146 ...
##
   $ Alch Rel
                        : num [1:2571] 6.58 6.56 7.66 7.14 7.14 7.16 6.54 6.52 6.52 6.54 ...
                        : num [1:2571] 5.32 5.3 5.84 5.42 5.44 5.44 5.38 5.34 5.34 5.34 ...
##
  $ Carb Rel
    $ Balling Lvl
                        : num [1:2571] 1.48 1.56 3.28 3.04 3.04 3.02 1.44 1.44 1.44 1.38 ...
summary(student_train)
##
     Brand Code
                         Carb Volume
                                          Fill Ounces
                                                            PC Volume
##
    Length: 2571
                        Min.
                               :5.040
                                         Min.
                                                :23.63
                                                          Min.
                                                                 :0.07933
##
    Class : character
                        1st Qu.:5.293
                                         1st Qu.:23.92
                                                          1st Qu.:0.23917
##
    Mode :character
                        Median :5.347
                                         Median :23.97
                                                          Median :0.27133
##
                        Mean
                               :5.370
                                         Mean
                                                :23.97
                                                          Mean
                                                                 :0.27712
##
                        3rd Qu.:5.453
                                         3rd Qu.:24.03
                                                          3rd Qu.:0.31200
##
                        Max.
                               :5.700
                                                :24.32
                                                                 :0.47800
                                         Max.
                                                          Max.
##
                                         NA's
                                                          NA's
                        NA's
                               :10
                                                :38
                                                                 :39
##
    Carb Pressure
                       Carb Temp
                                           PSC
                                                            PSC Fill
           :57.00
##
    Min.
                                                                :0.0000
                            :128.6
                                             :0.00200
                    Min.
                                     Min.
                                                         Min.
                                                         1st Qu.:0.1000
    1st Qu.:65.60
                     1st Qu.:138.4
                                      1st Qu.:0.04800
##
    Median :68.20
                     Median :140.8
                                     Median : 0.07600
                                                         Median :0.1800
##
    Mean
           :68.19
                     Mean
                            :141.1
                                     Mean
                                             :0.08457
                                                         Mean
                                                                :0.1954
##
    3rd Qu.:70.60
                                                         3rd Qu.:0.2600
                     3rd Qu.:143.8
                                      3rd Qu.:0.11200
##
    Max.
           :79.40
                            :154.0
                                     Max.
                                             :0.27000
                                                         Max.
                                                                :0.6200
                     Max.
    NA's
##
           :27
                     NA's
                            :26
                                      NA's
                                             :33
                                                         NA's
                                                                :23
       PSC CO2
##
                          Mnf Flow
                                          Carb Pressure1 Fill Pressure
##
   Min.
           :0.00000
                       Min.
                              :-100.20
                                          Min.
                                                 :105.6
                                                           Min.
                                                                  :34.60
##
    1st Qu.:0.02000
                       1st Qu.:-100.00
                                          1st Qu.:119.0
                                                           1st Qu.:46.00
##
    Median : 0.04000
                       Median: 65.20
                                          Median :123.2
                                                           Median :46.40
##
           :0.05641
    Mean
                       Mean
                              : 24.57
                                          Mean
                                                :122.6
                                                           Mean
                                                                  :47.92
##
    3rd Qu.:0.08000
                       3rd Qu.: 140.80
                                          3rd Qu.:125.4
                                                           3rd Qu.:50.00
                              : 229.40
##
    Max.
           :0.24000
                       Max.
                                          Max.
                                                 :140.2
                                                           Max.
                                                                  :60.40
##
    NA's
           :39
                       NA's
                                          NA's
                                                 :32
                                                           NA's
                                                                  :22
                              :2
    Hyd Pressure1
                                     Hyd Pressure3
##
                     Hyd Pressure2
                                                      Hyd Pressure4
    Min.
           :-0.80
                     Min.
                            : 0.00
                                             :-1.20
                                                              : 52.00
                                     Min.
                                                      Min.
                     1st Qu.: 0.00
##
    1st Qu.: 0.00
                                      1st Qu.: 0.00
                                                      1st Qu.: 86.00
##
    Median :11.40
                     Median :28.60
                                     Median :27.60
                                                      Median: 96.00
##
    Mean
           :12.44
                     Mean
                            :20.96
                                     Mean
                                             :20.46
                                                      Mean
                                                              : 96.29
    3rd Qu.:20.20
                     3rd Qu.:34.60
                                      3rd Qu.:33.40
                                                      3rd Qu.:102.00
           :58.00
                            :59.40
                                             :50.00
                                                              :142.00
##
    Max.
                     Max.
                                     Max.
                                                      Max.
##
    NA's
           :11
                     NA's
                            :15
                                     NA's
                                             :15
                                                      NA's
                                                              :30
##
     Filler Level
                      Filler Speed
                                      Temperature
                                                        Usage cont
                                                                         Carb Flow
    Min.
           : 55.8
                     Min.
                            : 998
                                     Min.
                                            :63.60
                                                             :12.08
                                                      Min.
                                                                      Min.
                                                                              : 26
                     1st Qu.:3888
##
    1st Qu.: 98.3
                                                      1st Qu.:18.36
                                     1st Qu.:65.20
                                                                       1st Qu.:1144
##
    Median :118.4
                     Median:3982
                                    Median :65.60
                                                      Median :21.79
                                                                      Median:3028
##
    Mean
           :109.3
                     Mean
                            :3687
                                     Mean
                                            :65.97
                                                      Mean
                                                             :20.99
                                                                       Mean
                                                                              :2468
    3rd Qu.:120.0
                                                      3rd Qu.:23.75
##
                     3rd Qu.:3998
                                     3rd Qu.:66.40
                                                                       3rd Qu.:3186
##
    Max.
           :161.2
                     Max.
                            :4030
                                     Max.
                                            :76.20
                                                      Max.
                                                             :25.90
                                                                       Max.
                                                                              :5104
    NA's
                     NA's
                                     NA's
##
           :20
                            :57
                                            :14
                                                      NA's
                                                             :5
                                                                      NA's
                                                                              :2
                                         Balling
##
       Density
                          MFR
                                                        Pressure Vacuum
                                            :-0.170
##
    Min.
           :0.240
                     Min.
                            : 31.4
                                     Min.
                                                        Min.
                                                               :-6.600
##
    1st Qu.:0.900
                     1st Qu.:706.3
                                      1st Qu.: 1.496
                                                        1st Qu.:-5.600
##
    Median :0.980
                     Median :724.0
                                     Median : 1.648
                                                        Median :-5.400
```

Mean :-5.216

3rd Qu.:-5.000

Mean : 2.198

3rd Qu.: 3.292

Mean :1.174

3rd Qu.:1.620

##

Mean :704.0

3rd Qu.:731.0

```
Max.
           :1.920
                           :868.6
                                    Max.
                                           : 4.012
                                                             :-3.600
                    Max.
##
                    NA's
                           :212
                                    NA's
   NA's
           :1
                                           : 1
                    Oxygen Filler
##
          PH
                                      Bowl Setpoint
                                                      Pressure Setpoint
                    Min.
                                                      Min.
##
           :7.880
                           :0.00240
                                             : 70.0
                                                              :44.00
   \mathtt{Min}.
                                      Min.
##
   1st Qu.:8.440
                    1st Qu.:0.02200
                                      1st Qu.:100.0
                                                      1st Qu.:46.00
##
   Median :8.540
                    Median :0.03340
                                      Median :120.0
                                                      Median :46.00
   Mean
         :8.546
                    Mean
                           :0.04684
                                      Mean :109.3
                                                      Mean
                                                             :47.62
##
   3rd Qu.:8.680
                    3rd Qu.:0.06000
                                      3rd Qu.:120.0
                                                      3rd Qu.:50.00
## Max.
           :9.360
                    Max.
                           :0.40000
                                     Max.
                                             :140.0
                                                      Max.
                                                              :52.00
##
                    NA's
  NA's
           :4
                           :12
                                      NA's
                                             :2
                                                      NA's
                                                              :12
## Air Pressurer
                       Alch Rel
                                       Carb Rel
                                                     Balling Lvl
## Min.
          :140.8
                           :5.280
                                           :4.960
                    Min.
                                    Min.
                                                    Min.
                                                           :0.00
  1st Qu.:142.2
                    1st Qu.:6.540
                                    1st Qu.:5.340
                                                    1st Qu.:1.38
## Median :142.6
                                                    Median:1.48
                    Median :6.560
                                    Median :5.400
## Mean
           :142.8
                           :6.897
                                           :5.437
                                                           :2.05
                    Mean
                                    Mean
                                                    Mean
##
   3rd Qu.:143.0
                    3rd Qu.:7.240
                                    3rd Qu.:5.540
                                                    3rd Qu.:3.14
## Max.
                                                            :3.66
           :148.2
                           :8.620
                                            :6.060
                    Max.
                                    Max.
                                                    Max.
##
                    NA's
                           :9
                                    NA's
                                            :10
                                                    NA's
                                                            :1
```

# # View Test Data

str(student test)

```
## tibble [267 x 33] (S3: tbl_df/tbl/data.frame)
                      : chr [1:267] "D" "A" "B" "B" ...
## $ Brand Code
   $ Carb Volume
                      : num [1:267] 5.48 5.39 5.29 5.27 5.41 ...
## $ Fill Ounces
                      : num [1:267] 24 24 23.9 23.9 24.2 ...
## $ PC Volume
                      : num [1:267] 0.27 0.227 0.303 0.186 0.16 ...
## $ Carb Pressure
                      : num [1:267] 65.4 63.2 66.4 64.8 69.4 73.4 65.2 67.4 66.8 72.6 ...
## $ Carb Temp
                      : num [1:267] 135 135 140 139 142 ...
## $ PSC
                      : num [1:267] 0.236 0.042 0.068 0.004 0.04 0.078 0.088 0.076 0.246 0.146 ...
## $ PSC Fill
                      : num [1:267] 0.4 0.22 0.1 0.2 0.3 ...
## $ PSC CO2
                      : num [1:267] 0.04 0.08 0.02 0.02 0.06 ...
## $ Mnf Flow
                      ## $ Carb Pressure1
                     : num [1:267] 117 119 120 125 115 ...
## $ Fill Pressure
                      : num [1:267] 46 46.2 45.8 40 51.4 46.4 46.2 40 43.8 40.8 ...
## $ Hyd Pressure1
                      : num [1:267] 0 0 0 0 0 0 0 0 0 0 ...
## $ Hyd Pressure2
                      : num [1:267] NA 0 0 0 0 0 0 0 0 ...
                      : num [1:267] NA 0 0 0 0 0 0 0 0 ...
## $ Hyd Pressure3
## $ Hyd Pressure4
                      : num [1:267] 96 112 98 132 94 94 108 108 110 106 ...
## $ Filler Level
                      : num [1:267] 129 120 119 120 116 ...
## $ Filler Speed
                      : num [1:267] 3986 4012 4010 NA 4018 ...
## $ Temperature
                      : num [1:267] 66 65.6 65.6 74.4 66.4 66.6 66.8 NA 65.8 66 ...
## $ Usage cont
                      : num [1:267] 21.7 17.6 24.2 18.1 21.3 ...
## $ Carb Flow
                      : num [1:267] 2950 2916 3056 28 3214 ...
## $ Density
                      : num [1:267] 0.88 1.5 0.9 0.74 0.88 0.84 1.48 1.6 1.52 1.48 ...
## $ MFR
                      : num [1:267] 728 736 735 NA 752 ...
## $ Balling
                      : num [1:267] 1.4 2.94 1.45 1.06 1.4 ...
## $ Pressure Vacuum : num [1:267] -3.8 -4.4 -4.2 -4 -4 -3.8 -4.2 -4.4 -4.4 -4.2 ...
## $ PH
                      : logi [1:267] NA NA NA NA NA NA ...
## $ Oxygen Filler
                      : num [1:267] 0.022 0.03 0.046 NA 0.082 0.064 0.042 0.096 0.046 0.096 ...
##
   $ Bowl Setpoint
                      : num [1:267] 130 120 120 120 120 120 120 120 120 120 ...
## $ Pressure Setpoint: num [1:267] 45.2 46 46 46 50 46 46 46 46 ...
                    : num [1:267] 143 147 147 146 146 ...
## $ Air Pressurer
## $ Alch Rel
                      : num [1:267] 6.56 7.14 6.52 6.48 6.5 6.5 7.18 7.16 7.14 7.78 ...
```

```
## $ Carb Rel : num [1:267] 5.34 5.58 5.34 5.5 5.38 5.42 5.46 5.42 5.44 5.52 ... ## $ Balling Lvl : num [1:267] 1.48 3.04 1.46 1.48 1.46 1.44 3.02 3 3.1 3.12 ...
```

#### summary(student\_test)

```
##
     Brand Code
                        Carb Volume
                                         Fill Ounces
                                                           PC Volume
                               :5.147
                                                :23.75
                                                                :0.09867
##
    Length: 267
                        Min.
                                        Min.
                                                         Min.
    Class : character
                       1st Qu.:5.287
                                        1st Qu.:23.92
                                                         1st Qu.:0.23333
    Mode : character
                        Median :5.340
                                        Median :23.97
                                                         Median: 0.27533
##
                        Mean
                               :5.369
                                        Mean
                                               :23.97
                                                         Mean
                                                                :0.27769
##
                        3rd Qu.:5.465
                                        3rd Qu.:24.01
                                                         3rd Qu.:0.32200
##
                               :5.667
                                                :24.20
                                                                :0.46400
                        Max.
                                        Max.
                                                         Max.
##
                        NA's
                               :1
                                        NA's
                                                :6
                                                         NA's
                                                                :4
                                          PSC
##
    Carb Pressure
                       Carb Temp
                                                           PSC Fill
           :60.20
                    Min.
                           :130.0
                                            :0.00400
                                                               :0.0200
                                     Min.
                                                        Min.
                    1st Qu.:138.4
                                     1st Qu.:0.04450
                                                        1st Qu.:0.1000
##
    1st Qu.:65.30
##
    Median :68.00
                    Median :140.8
                                     Median :0.07600
                                                        Median :0.1800
##
    Mean
           :68.25
                    Mean
                           :141.2
                                     Mean
                                            :0.08545
                                                        Mean
                                                               :0.1903
    3rd Qu.:70.60
                    3rd Qu.:143.8
                                     3rd Qu.:0.11200
                                                        3rd Qu.:0.2600
##
    Max.
           :77.60
                    Max.
                            :154.0
                                     Max.
                                             :0.24600
                                                        Max.
                                                               :0.6200
                                     NA's
                                            :5
                                                        NA's
##
                    NA's
                           :1
                                                               :3
##
       PSC CO2
                         Mnf Flow
                                         Carb Pressure1 Fill Pressure
##
    Min.
           :0.00000
                      Min.
                            :-100.20
                                         Min.
                                                :113.0
                                                          Min.
                                                                 :37.80
                                         1st Qu.:120.2
    1st Qu.:0.02000
                      1st Qu.:-100.00
##
                                                          1st Qu.:46.00
    Median : 0.04000
                      Median :
                                  0.20
                                         Median :123.4
                                                          Median :47.80
##
    Mean
           :0.05107
                      Mean
                            : 21.03
                                         Mean
                                               :123.0
                                                          Mean
                                                                 :48.14
    3rd Qu.:0.06000
                       3rd Qu.: 141.30
                                         3rd Qu.:125.5
                                                          3rd Qu.:50.20
                            : 220.40
##
    Max.
           :0.24000
                      Max.
                                         Max.
                                                 :136.0
                                                          Max.
                                                                 :60.20
           :5
                                                :4
##
    NA's
                                                          NA's
                                         NA's
                                                                 :2
    Hyd Pressure1
                     Hyd Pressure2
                                       Hyd Pressure3
                                                         Hyd Pressure4
                                              :-50.00
##
    Min.
          :-50.00
                     Min.
                            :-50.00
                                       Min.
                                                         Min.
                                                                : 68.00
    1st Qu.: 0.00
                     1st Qu.: 0.00
                                       1st Qu.: 0.00
                                                         1st Qu.: 90.00
                     Median : 26.80
##
    Median : 10.40
                                       Median : 27.70
                                                         Median: 98.00
    Mean
          : 12.01
                     Mean
                            : 20.11
                                       Mean
                                             : 19.61
                                                         Mean
                                                                : 97.84
    3rd Qu.: 20.40
                     3rd Qu.: 34.80
##
                                       3rd Qu.: 33.00
                                                         3rd Qu.:104.00
##
    Max. : 50.00
                     Max.
                             : 61.40
                                       Max.
                                              : 49.20
                                                         Max.
                                                                :140.00
##
                     NA's
                                       NA's
                                                         NA's
                             :1
                                              :1
                                                                :4
    Filler Level
                     Filler Speed
                                     Temperature
                                                       Usage cont
                                                                       Carb Flow
   Min. : 69.2
                           :1006
                                    Min.
                                                           :12.90
##
                    Min.
                                           :63.80
                                                     Min.
                                                                     Min.
                                                                            :
    1st Qu.:100.6
                    1st Qu.:3812
##
                                    1st Qu.:65.40
                                                     1st Qu.:18.12
                                                                     1st Qu.:1083
##
   Median :118.6
                    Median:3978
                                    Median :65.80
                                                     Median :21.44
                                                                     Median:3038
    Mean
          :110.3
                    Mean
                           :3581
                                    Mean
                                           :66.23
                                                     Mean
                                                            :20.90
                                                                     Mean
                                                                            :2409
                                    3rd Qu.:66.60
##
    3rd Qu.:120.2
                    3rd Qu.:3996
                                                     3rd Qu.:23.74
                                                                      3rd Qu.:3215
##
    Max.
           :153.2
                    Max.
                            :4020
                                    Max.
                                           :75.40
                                                     Max.
                                                            :24.60
                                                                     Max.
                                                                             :3858
    NA's
                                    NA's
##
           :2
                    NA's
                            :10
                                           :2
                                                     NA's
                                                            :2
##
                         MFR
                                                      Pressure Vacuum
       Density
                                        Balling
##
    Min.
           :0.060
                    Min.
                            : 15.6
                                     Min.
                                            :0.902
                                                      Min.
                                                             :-6.400
                    1st Qu.:707.0
##
    1st Qu.:0.920
                                     1st Qu.:1.498
                                                      1st Qu.:-5.600
    Median : 0.980
                    Median :724.6
                                     Median :1.648
                                                      Median :-5.200
                                           :2.203
##
    Mean
           :1.177
                    Mean
                            :697.8
                                     Mean
                                                      Mean
                                                            :-5.174
##
    3rd Qu.:1.600
                    3rd Qu.:731.5
                                     3rd Qu.:3.242
                                                      3rd Qu.:-4.800
           :1.840
##
    Max.
                    Max.
                            :784.8
                                     Max.
                                             :3.788
                                                      Max.
                                                             :-3.600
##
    NA's
                    NA's
                            :31
                                     NA's
                                             :1
                                                      NA's
                                                             :1
##
       PH
                   Oxygen Filler
                                      Bowl Setpoint
                                                     Pressure Setpoint
```

```
:0.00240
                                                : 70.0
    Mode:logical
                    Min.
                                        Min.
                                                          Min.
                                                                 :44.00
    NA's:267
                                        1st Qu.:100.0
##
                    1st Qu.:0.01960
                                                          1st Qu.:46.00
                                        Median :120.0
##
                    Median : 0.03370
                                                         Median :46.00
##
                    Mean
                            :0.04666
                                        Mean
                                                :109.6
                                                         Mean
                                                                 :47.73
##
                    3rd Qu.:0.05440
                                        3rd Qu.:120.0
                                                          3rd Qu.:50.00
                            :0.39800
                                                :130.0
##
                                                         Max.
                                                                 :52.00
                    Max.
                                        Max.
##
                    NA's
                            :3
                                        NA's
                                                :1
                                                          NA's
                                                                 :2
##
    Air Pressurer
                         Alch Rel
                                          Carb Rel
                                                        Balling Lvl
##
    Min.
            :141.2
                     Min.
                             :6.400
                                               :5.18
                                                       Min.
                                                               :0.000
                                       Min.
##
    1st Qu.:142.2
                     1st Qu.:6.540
                                       1st Qu.:5.34
                                                       1st Qu.:1.380
    Median :142.6
                     Median :6.580
                                       Median:5.40
                                                       Median :1.480
##
    Mean
            :142.8
                     Mean
                             :6.907
                                       Mean
                                               :5.44
                                                       Mean
                                                               :2.051
##
    3rd Qu.:142.8
                     3rd Qu.:7.180
                                       3rd Qu.:5.56
                                                       3rd Qu.:3.080
            :147.2
                             :7.820
                                               :5.74
##
    Max.
                     Max.
                                       Max.
                                                       Max.
                                                               :3.420
##
    NA's
                     NA's
                             :3
                                       NA's
                                               :2
            :1
```

From the above summaries, we can see that the majority of predictors are numeric with the sole exception of Brand Code which is a string that appears to represent categorical information. That will need to be converted into a factor. From the summaries, we can see that there are a few NULL entries. In the next cell, we'll investigate how many there are.

## Checking for Null Entries

```
# View the number Null entries in the training data
na_counts_train <- data.frame(null_count = colSums(is.na(student_train)))
na_counts_train$percentage <- (na_counts_train$null_count / nrow(student_train)) * 100
na_counts_train</pre>
```

```
##
                      null_count percentage
## Brand Code
                             120 4.66744457
## Carb Volume
                              10 0.38895371
                              38 1.47802412
## Fill Ounces
## PC Volume
                              39 1.51691949
## Carb Pressure
                              27 1.05017503
## Carb Temp
                              26 1.01127966
## PSC
                              33 1.28354726
## PSC Fill
                              23 0.89459354
## PSC CO2
                              39 1.51691949
## Mnf Flow
                               2 0.07779074
## Carb Pressure1
                              32 1.24465189
## Fill Pressure
                              22 0.85569817
## Hyd Pressure1
                              11 0.42784909
## Hyd Pressure2
                              15 0.58343057
## Hyd Pressure3
                              15 0.58343057
## Hyd Pressure4
                              30 1.16686114
## Filler Level
                              20 0.77790743
## Filler Speed
                              57 2.21703617
## Temperature
                              14 0.54453520
## Usage cont
                               5 0.19447686
## Carb Flow
                               2 0.07779074
## Density
                               1 0.03889537
```

```
## MFR
                             212 8.24581875
## Balling
                               1 0.03889537
## Pressure Vacuum
                               0 0.00000000
                               4 0.15558149
## Oxygen Filler
                              12 0.46674446
## Bowl Setpoint
                              2 0.07779074
## Pressure Setpoint
                             12 0.46674446
## Air Pressurer
                              0 0.00000000
## Alch Rel
                               9 0.35005834
## Carb Rel
                              10 0.38895371
## Balling Lvl
                               1 0.03889537
na_counts_test <- data.frame(null_count = colSums(is.na(student_test)))</pre>
na_counts_test$percentage <- (na_counts_test$null_count / nrow(student_test)) * 100</pre>
na_counts_test
```

```
##
                     null_count
                                 percentage
## Brand Code
                                  2.9962547
## Carb Volume
                              1
                                  0.3745318
## Fill Ounces
                                  2.2471910
## PC Volume
                                  1.4981273
## Carb Pressure
                                 0.0000000
                                  0.3745318
## Carb Temp
                              1
                              5
## PSC
                                  1.8726592
## PSC Fill
                              3
                                 1.1235955
## PSC CO2
                              5
                                 1.8726592
## Mnf Flow
                              0
                                 0.0000000
## Carb Pressure1
                              4
                                  1.4981273
## Fill Pressure
                              2
                                 0.7490637
## Hyd Pressure1
                              0
                                 0.0000000
## Hyd Pressure2
                              1
                                  0.3745318
## Hyd Pressure3
                                 0.3745318
                              1
## Hyd Pressure4
                                 1.4981273
## Filler Level
                              2
                                 0.7490637
## Filler Speed
                             10
                                  3.7453184
## Temperature
                              2
                                  0.7490637
## Usage cont
                                  0.7490637
## Carb Flow
                              0
                                  0.000000
## Density
                              1
                                  0.3745318
                             31 11.6104869
## MFR
## Balling
                                  0.3745318
## Pressure Vacuum
                                  0.3745318
                              1
## PH
                            267 100.0000000
## Oxygen Filler
                              3 1.1235955
## Bowl Setpoint
                                  0.3745318
## Pressure Setpoint
                              2
                                 0.7490637
## Air Pressurer
                                  0.3745318
                              1
## Alch Rel
                              3
                                  1.1235955
## Carb Rel
                              2
                                  0.7490637
## Balling Lvl
                                  0.000000
```

From the above null counts, we can see that there are a quite a few NULL values across most of the predictors in our data and a few in our dependent. We will need to account for these NULL values.

For the independent NULL values, we've elected to drop them as we have 2,571 total records and dropping these NULL values will only result in 4 records being omitted which we don't believe will impact the results greatly as we already have so many total records.

For the independent NULL values, we can fill these by using imputation. Our method of choice will be to kNN to fill these values.

# 5. Data Pre-Processing

## Removing predictors with Little to No Variance

Using the function nearZeroVar() we can remove entries. This will help our models' performance and help avoid overfitting.

```
# use nearZeroVar to remove 0 variance items from the training dataset
student_train_with_variance <- student_train[, -nearZeroVar(student_train)]
# Use colnames to select values from the testing dataset
student_test_with_variance <- student_test |>
    select(colnames(student_train_with_variance))
```

## Removing data with NULL Dependents

```
# Removing null PH from the training dataset
student_train_no_null_PH <- student_train_with_variance |>
filter(!is.na(PH))
```

#### Imputing Data using KNN and Converting Brand Code

To impute the data, we'll use KNN to fill the training dataset and use that KNN model to fill the missing data for the testing dataset.

```
# Setting the PH of the testing dataset to 0
student_test_with_variance$PH[is.na(student_test_with_variance$PH)] <- 0

# Combine train and test data
combined_data <- bind_rows(
    mutate(student_train_no_null_PH, dataset = "train"),
    mutate(student_test_with_variance, dataset = "test")
)

# Convert Brand Code into a factor
combined_data <- combined_data |>
    mutate("Brand Code" = as.factor(`Brand Code`))

# Impute combined data
imputed_data <- kNN(combined_data, k = 5)

# Separate back into train and test</pre>
```

```
train_data <- imputed_data |>
  filter(dataset == "train") |>
  select(-dataset) |>
  select(-ends_with("_imp"))

test_data <- imputed_data |>
  filter(dataset == "test") |>
  select(-dataset) |>
  select(-ends_with("_imp"))

dim(train_data)
```

## [1] 2567 32

## Centering, Scaling, and Splitting the Data

```
\# Split the data into train and test dataframes
training_x <- train_data |>
  select(-PH)
training_y <- train_data |>
  select(PH)
test_x <- test_data |>
  select(-PH)
# Create a preProcess function model using the training dataset
preprocess_apply <- preProcess(</pre>
  training_x,
  method = c(
    "center",
    "scale"
)
# Apply the preprocessing to the training and testing dataset
train_preprocessed <- predict(</pre>
  preprocess_apply,
  training_x
test_preprocessed <- predict(</pre>
  preprocess_apply,
  test_x
)
```

Now that we've performed the centering and scaling on the independent values we will split the train\_preprocessed into training and validation datasets.

```
set.seed(1994)
# Use the sample function to create a random 80/20 split
```

```
train_rows <- sample(
    seq_len(nrow(train_preprocessed)),
    size = 0.8 * nrow(train_preprocessed)
)

train_x <- train_preprocessed[train_rows, ]

train_y <- training_y[train_rows, ]

validation_x <- train_preprocessed[-train_rows, ]

validation_y <- training_y[-train_rows, ]</pre>
```

With this section complete, we now have a few datasets which we will use as we train our models:

- 1. train\_x The independent dataset which we will train from
- 2. validation\_x The independent dataset which we will assess models using
- 3. train\_y The dependent values corresponding to the train\_x dataset
- 4. validation\_y The dependent values corresponding to the validaiton\_x dataset
- 5. test\_x Our preprocessed indpendent data representing the unknown data from the manufacturing floor

With these steps completed, we are ready to begin training our models.

# 6. Model Creation

#### Setup

In order to assess these models later we will initialize a dataframe which will retain all of our performance metrics across the validation dataset.

```
# Create an empty dataframe to store results
model_results <- data.frame(
   Model = character(),
   RMSE = numeric(),
   R_Squared = numeric(),
   MAE = numeric(),
   stringsAsFactors = FALSE
)</pre>
```

Now we will specify the cross-validation that we will apply as we built out our models:

```
global_trcontrol <- trainControl(
  method = "cv",
  allowParallel = TRUE
)</pre>
```

#### A. Ordinary Linear Regression

```
model_type = "Ordinary Linear Regression"
# Set a seed to today's date
set.seed(1994)
# Train our OLR model
olr_model <- train(</pre>
 x = train x,
 y = train_y,
 method = "lm",
 trControl = global_trcontrol
# Obtain predictions for our model
model_predictions <- predict(</pre>
  olr_model,
  newdata = validation_x
# Obtain performance metrics for our trained model on unseen data
model_metrics <- postResample(</pre>
 model_predictions,
  validation_y
)
# Store these results in our "model_results" dataframe
model_results <- rbind(model_results, data.frame(</pre>
 Model = model_type,
  RMSE = model_metrics["RMSE"],
 R_Squared = model_metrics["Rsquared"],
 MAE = model_metrics["MAE"]
))
```

```
model_metrics
```

```
## RMSE Rsquared MAE
## 0.1290943 0.4323892 0.1016434
```

## B. Partial Least Squares (PLS)

```
model_type = "Partial Least Squares"

set.seed(1994)

# Train our model
pls_model <- train(
    train_x,
    train_y,
    method = "pls",
    tuneLength = 20,
    trControl = global_trcontrol</pre>
```

```
# Obtain predictions for our model
model_predictions <- predict(
    pls_model,
    newdata = validation_x
)

# Obtain performance metrics for our trained model on unseen data
model_metrics <- postResample(
    model_predictions,
    validation_y
)

# Store these results in our "model_results" dataframe
model_results <- rbind(model_results, data.frame(
    Model = model_type,
    RMSE = model_metrics["RMSE"],
    R_Squared = model_metrics["Rsquared"],
    MAE = model_metrics["MAE"]
))</pre>
```

```
## RMSE Rsquared MAE
## 0.1298032 0.4261621 0.1019854
```

#### C. Neural Network Model

A neural network cannot have factors as an input. To account this, factors must be converted into numeric representations which is what have done below:

```
# Use Dummy Variables to convert the factor into a numeric
train_x_with_dummies <- cbind(</pre>
 train_x,
 model.matrix(
   ~ `Brand Code` - 1,
    data = train_x
  )
  ) |>
  select(-`Brand Code`)
validation_x_with_dummies <- cbind(</pre>
  validation_x,
  model.matrix(
    ~ `Brand Code` - 1,
    data = validation_x
 )
) |>
 select(-`Brand Code`)
```

A neural network will require correlated items to be removed because they introduce redundancy, which

can lead to inefficiencies and instability during training. Additionally, removing them reduces the risk of overfitting and helps the model generalize better to new data.

```
# Collect items with high correlations
nn_high_correlation <- findCorrelation(cor(train_x_with_dummies), cutoff = 0.75)
nn_train_x <- train_x_with_dummies[, -nn_high_correlation]
nn_validation_x <- validation_x_with_dummies[, -nn_high_correlation]</pre>
```

```
model_type = "Neural Network"
# Set our Neural Network Tuning Grid
nnet_grid <- expand.grid(</pre>
  .decay = seq(0, .2, by = .05),
  .size = c(3:8)
# Set a seed to today's date
set.seed(1994)
# Train our model
nnet_model <- train(</pre>
  train_x_with_dummies,
 train_y,
  method = "nnet",
  tuneGrid = nnet_grid,
  trControl = global trcontrol,
 MaxNWts = 10 * (ncol(train_x) + 1) + 10 + 1,
  maxit = 500,
 linout = TRUE,
  trace = FALSE
)
# Obtain predictions for our model
model_predictions <- predict(</pre>
  nnet_model,
  newdata = validation_x_with_dummies
# Obtain performance metrics for our trained model on unseen data
model_metrics <- postResample(</pre>
 model_predictions,
  validation_y
)
# Store these results in our "model results" dataframe
model_results <- rbind(model_results, data.frame(</pre>
  Model = model_type,
  RMSE = model_metrics["RMSE"],
  R_Squared = model_metrics["Rsquared"],
  MAE = model_metrics["MAE"]
))
```

```
model_metrics
```

```
## RMSE Rsquared MAE
## 0.12164761 0.50970105 0.09266492
```

## D. Multivariate Adaptive Regression Splines (MARS)

```
model_type = "MARS"
# Set a seed to today's date
set.seed(1994)
# Set Mars Tune Grid
mars_grid <- expand.grid(</pre>
  .degree = 1:4,
  .nprune = 2:40
# Train our model
mars_model <- train(</pre>
  train_x,
 train_y,
 method = "earth",
 tuneGrid = mars_grid,
  trControl = global_trcontrol
)
# Obtain predictions for our model
model_predictions <- predict(</pre>
  mars_model,
  newdata = validation_x
# Obtain performance metrics for our trained model on unseen data
model_metrics <- postResample(</pre>
  model_predictions,
  validation_y
)
# Store these results in our "model_results" dataframe
model_results <- rbind(model_results, data.frame(</pre>
 Model = model_type,
  RMSE = model_metrics["RMSE"],
  R_Squared = model_metrics["Rsquared"],
  MAE = model_metrics["MAE"]
))
```

model\_metrics

```
## RMSE Rsquared MAE
## 0.13472022 0.41935348 0.09999733
```

# E. Support Vector Machines (SVM)

Similar to the Neural Network, we will need to use Dummies for this model:

```
model_type = "SVM"
# Set a seed to today's date
set.seed(1994)
# Train our model
svm_model <- train(</pre>
  train_x_with_dummies,
 train_y,
 method = "svmRadial",
 tuneLength = 14,
  trControl = global_trcontrol
# Obtain predictions for our model
model_predictions <- predict(</pre>
  svm_model,
  newdata = validation_x_with_dummies
)
# Obtain performance metrics for our trained model on unseen data
model_metrics <- postResample(</pre>
  model_predictions,
  validation_y
# Store these results in our "model_results" dataframe
model_results <- rbind(model_results, data.frame(</pre>
 Model = model_type,
 RMSE = model_metrics["RMSE"],
  R_Squared = model_metrics["Rsquared"],
  MAE = model_metrics["MAE"]
))
```

```
model_metrics
```

```
## RMSE Rsquared MAE
## 0.1147053 0.5604292 0.0859519
```

## F. K-Nearest Neighbors (KNN)

```
model_type = "KNN"

# Set a seed to today's date
set.seed(1994)

# KNN Tune Grid
```

```
knn_grid <- expand.grid(</pre>
  .k = 1:20
# Train our model
knn_model <- train(</pre>
 train_x_with_dummies,
 train_y,
 method = "knn",
 tuneGrid = knn_grid,
 trControl = global_trcontrol
)
# Obtain predictions for our model
model_predictions <- predict(</pre>
 knn_model,
  newdata = validation_x_with_dummies
# Obtain performance metrics for our trained model on unseen data
model_metrics <- postResample(</pre>
  model_predictions,
  validation_y
)
# Store these results in our "model_results" dataframe
model_results <- rbind(model_results, data.frame(</pre>
 Model = model_type,
 RMSE = model_metrics["RMSE"],
 R_Squared = model_metrics["Rsquared"],
 MAE = model_metrics["MAE"]
))
```

## RMSE Rsquared MAE ## 0.11957078 0.51936213 0.08987493

#### G. Random Forest

```
model_type = "Random Forest"

# Set a seed to today's date
set.seed(1994)

# Train our model
rf_model <- randomForest(
   train_x,
   train_y,
   importance = TRUE,
   ntress = 1000</pre>
```

```
# Obtain predictions for our model
model_predictions <- predict(
    rf_model,
    newdata = validation_x
)

# Obtain performance metrics for our trained model on unseen data
model_metrics <- postResample(
    model_predictions,
    validation_y
)

# Store these results in our "model_results" dataframe
model_results <- rbind(model_results, data.frame(
    Model = model_type,
    RMSE = model_metrics["RMSE"],
    R_Squared = model_metrics["Rsquared"],
    MAE = model_metrics["MAE"]
))</pre>
```

## RMSE Rsquared MAE ## 0.09746611 0.69074149 0.07416578

## H. Boosted Trees

```
model_type = "Boosted Trees"
# Set a seed to today's date
set.seed(1994)
# Set a tuning grid for our model
boosted_grid <- expand.grid(</pre>
  .interaction.depth = seq(1, 7, by = 2),
  .n.trees = seq(100, 1000, by = 50),
  .shrinkage = c(.01, .1),
  .n.minobsinnode = seq(1, 15, by = 5)
)
# Train our model
boosted_animals <- train(</pre>
 train_x,
 train_y,
  method = "gbm",
 tuneGrid = boosted_grid,
  trControl = trainControl(method = "cv", allowParallel = TRUE),
  verbose = FALSE
```

```
# Obtain predictions for our model
model_predictions <- predict(</pre>
  boosted_animals,
  newdata = validation_x
)
# Obtain performance metrics for our trained model on unseen data
model metrics <- postResample(</pre>
  model_predictions,
  validation_y
# Store these results in our "model_results" dataframe
model_results <- rbind(model_results, data.frame(</pre>
 Model = model_type,
  RMSE = model_metrics["RMSE"],
  R_Squared = model_metrics["Rsquared"],
 MAE = model_metrics["MAE"]
))
```

```
## RMSE Rsquared MAE
## 0.09927913 0.66402274 0.07673660
```

# 10. Cubist

```
model_type = "Cubist"
# Set a seed to today's date
set.seed(1994)
# Train our model
cubist_model <- train(</pre>
  train_x,
 train_y,
 method = "cubist"
# Obtain predictions for our model
model_predictions <- predict(</pre>
  cubist_model,
  newdata = validation_x
# Obtain performance metrics for our trained model on unseen data
model_metrics <- postResample(</pre>
 model_predictions,
  validation_y
)
```

```
# Store these results in our "model_results" dataframe
model_results <- rbind(model_results, data.frame(
    Model = model_type,
    RMSE = model_metrics["RMSE"],
    R_Squared = model_metrics["Rsquared"],
    MAE = model_metrics["MAE"]
))</pre>
```

```
## RMSE Rsquared MAE
## 0.09719990 0.67862646 0.07120253
```

#7. Model Evaluation & Selection

```
model_results |>
arrange(desc(R_Squared))
```

```
##
                              Model
                                           RMSE R_Squared
                                                                 MAE
## RMSE6
                      Random Forest 0.09746611 0.6907415 0.07416578
                             Cubist 0.09719990 0.6786265 0.07120253
## RMSE8
## RMSE7
                      Boosted Trees 0.09927913 0.6640227 0.07673660
## RMSE4
                                SVM 0.11470532 0.5604292 0.08595190
                                KNN 0.11957078 0.5193621 0.08987493
## RMSE5
## RMSE2
                     Neural Network 0.12164761 0.5097011 0.09266492
         Ordinary Linear Regression 0.12909425 0.4323892 0.10164336
## RMSE
## RMSE1
              Partial Least Squares 0.12980323 0.4261621 0.10198539
## RMSE3
                               MARS 0.13472022 0.4193535 0.09999733
```

Of all the simulations, Random Forest model has the best  $R^2$  among the lowest MAE and RMSE. Across these metrics, it's a fairly obvious choice to use the Random Forest model for our predictions on the provided data

```
varImp(rf_model) |>
arrange(desc(Overall))
```

```
##
                        Overall
## Brand Code
                      43.710738
## Mnf Flow
                      41.586138
## Pressure Vacuum
                      34.576455
## Oxygen Filler
                      34.375752
## Temperature
                      28.166384
## Balling Lvl
                      27.760413
## Air Pressurer
                      27.361551
## Carb Rel
                      26.484431
## Usage cont
                      26.211265
## Alch Rel
                      24.427996
## Carb Flow
                      22.990695
## Balling
                      22.643556
## Filler Speed
                      22.563888
## Bowl Setpoint
                      22.556331
```


```
## Carb Pressure1
                     22.112041
## Density
                     21.818851
## Filler Level
                     19.439339
## Hyd Pressure3
                     18.078035
## Hyd Pressure4
                     15.974959
## MFR
                     15.055687
## Carb Volume
                     14.757701
## Hyd Pressure2
                     13.912087
## PC Volume
                     12.075740
## Fill Pressure
                     11.825428
## Pressure Setpoint 9.979172
## Fill Ounces
                      3.164861
## Carb Pressure
                      2.009370
## Carb Temp
                      1.959494
## PSC CO2
                      1.446354
## PSC Fill
                      1.443249
## PSC
                      1.277980
```

The most important variables were Brand Code, closely followed by Mnf Flow and Pressure Vacuum. Interestingly, Carb Temp has a negative overall score. We can get a sense of how well these predictors apply to PH by looking at a correlation plot of the top few predictors:

```
top_8_predictors <- varImp(rf_model) |>
    arrange(desc(Overall)) |>
    head(8) |>
    tail(7) |>
    row.names()

brand_code_vars = c("`Brand Code`A", "`Brand Code`B", "`Brand Code`C", "`Brand Code`D")

train_x_with_dummies |>
    cbind(train_y) |>
    rename(
    PH = train_y) |>
    select(
        c('PH', top_8_predictors, brand_code_vars)) |>
    cor() |>
    corrplot()
```



From this correlation plot, we can see that there seems to be a relatively strong negative correlation between Mnf Flow and the C Brand Code.

# 8. Model Forecast

write.csv(
 cbind(
 test\_y,
 test\_x
) |>

Now that we have our model selected, we will use it to predict the unknown data from ABC Beverage:

```
test_y = predict(
    rf_model,
    test_x
)

# Record the start time
start_time <- Sys.time()

# Introduce a delay for testing (e.g., 2 seconds)
Sys.sleep(2)

# Save predictions to a CSV file</pre>
```

```
rename(
      prediction = test_y
    ),
  "abc_beverage_model_output.csv",
  row.names = FALSE
# Record the end time
end time <- Sys.time()
# Calculate the duration
duration <- difftime(end_time, start_time, units = "secs")</pre>
total_seconds <- as.numeric(duration)</pre>
# Calculate hours, minutes, and seconds as integers
hours <- as.integer(total_seconds %/% 3600)
minutes <- as.integer((total_seconds %% 3600) %/% 60)
seconds <- as.integer(total_seconds %% 60)</pre>
# Format the duration as HH:MM:SS
pretty_duration <- sprintf("Duration: %02d:%02d:%02d", hours, minutes, seconds)</pre>
# Print the result
print(pretty_duration)
```

#### ## [1] "Duration: 00:00:03"

#### Conclusion:

After evaluating several predictive models for estimating the pH levels in ABC Beverage's manufacturing process, the Random Forest model emerged as the most effective solution. It demonstrated the highest predictive accuracy, achieving an R-squared value of approximately 0.69, with an RMSE of 0.0976 and a MAE of 0.0743. These metrics indicate that the Random Forest model explains 69% of the variability in pH levels and provides robust and reliable predictions.

This success is attributable to the robustness of Random Forest in handling complex, non-linear relationships and its ability to mitigate overfitting through ensemble learning. The model's performance highlights its potential to provide actionable insights into the manufacturing process. By leveraging key predictors such as "Brand Code," "Manufacturing Flow," and "Pressure Vacuum," the model offers a comprehensive understanding of the variables impacting pH levels.

The preprocessing steps played a crucial role in the model's success. Specifically, techniques like K-Nearest Neighbor (kNN) imputation for missing data and removal of low-variance predictors ensured the dataset was clean and optimized for analysis. Additionally, rigorous cross-validation provided confidence in the model's generalizability to unseen data.

The results underline the importance of integrating data-driven approaches into manufacturing workflows. The insights generated by the Random Forest model can be used not only to meet regulatory requirements but also to proactively identify and address potential issues in the production process, leading to enhanced operational efficiency and product consistency. Future updates to the model can incorporate new data to further refine its accuracy and applicability.

#### Results:

**Key Findings:** 

The most influential factors for predicting pH levels included "Brand Code," "Manufacturing Flow," and "Pressure Vacuum," among others.

The data preprocessing steps, including K-Nearest Neighbor (kNN) imputation and removal of low-variance predictors, were instrumental in improving model performance.

Cross-validation and careful hyperparameter tuning across models ensured that the results were generalizable and not overfitted to the training data.

#### Model Comparisons:

Random Forest: Best performance with R-squared = 0.69.

Cubist Model: Second-best performance with R-squared = 0.66.

Other models (e.g., Neural Networks, Boosted Trees) provided acceptable but less accurate predictions.

#### Forecast Output:

Predictions for the provided "new" dataset were generated using the Random Forest model and exported to an Excel-readable format. These predictions will assist in regulatory compliance and process optimization.

Recommendations for Next Steps:

Utilize the predictive insights to monitor and adjust manufacturing processes for optimal pH control.

Investigate flagged predictions or anomalies to uncover potential process inefficiencies or deviations.